
## PARTS LIST

CIRCULAR SAW

Model Number Effective Date Form Number

15687E1 6-15-74 20824L1



ITEM NO. PART NO. DESCRIPTION			
1 180122 Bolt, Hex 3/	8-16	X	1
2 180181 Bolt, Hex 1/	2-13	X	2
3 13150P1 Collar, Guar	d		
4 10120A1 Rim, Assembl			
5 13479P1 Blade, 18 In	. Sar	W	

BrentChalmers.com